

**This is supplemental instructions on how to install the bumper stops on the  
Tracks A-Frame Only**



**These are installed to keep the the locking bar on the tracks A-Frame from coming in contact with the unit itself if the plow rides up onto a snow pile.**

**There are multiple mounting locations on both the bumper stop mounting bracket and on the track A-Frame. The bumper stops can also be mounted on either side of the bumper stop mounting bracket.**

**How they are installed varies on which unit the track A-Frame is mounted on.**

**You will need 2 - 9/16 wrenches and a pliers for installation**

- 1. The first step is to completely assemble the plow and install on the unit.**
- 2. Raise the plow all the way up with the winch**
- 3. At this point, no part of the plow A-Frame should come on contact with the unit.**
- 4. Grab ahold of the bottom of the plow and lift up reenacting what would happen if the plow rides up onto a snow pile.**
- 5. Take note of where it stops and mount the bumper stops in a mounting location on the tracks A-Frame to where when this does happen, the bumper stops will come in contact with the unit before the track A-Frame assembly (pictures below are on a Polaris 900/1000).**

